



All seen from
Wire side



WH-F57	STALL WARNING
WH-L72	LEFT NAV LIGHTS
WH-B184	NAV LEFT TO RIGHT
WH-B212	NAV STROBE POWER WIRE
WH-L88	LANDING LIGHT
WH-L73	LANDING LIGHT PULSE
WH-B213	LANDING LIGHT PULSE
WH-B214	LANDING LIGHT POWER